



STUDIO RANGE - POLISHED NICKEL


Rocker Light Switches




Y08.200.PN
1 Gang Rocker Switch (10
Amp)




Y08.210.PN
2 Gang Rocker Switch (10
Amp)



Y08.220.PN
3 Gang Rocker Switch (10
Amp)




Y08.230.PN
4 Gang Rocker Switch (10 Amp)




Y08.201.PN
1 Gang Intermediate Rocker Switch (10
Amp)


Classic Toggle Switches




Y08.2400.PN
1 Gang Toggle Switch




Y08.2410.PN
2 Gang Toggle Switch



Y08.2420.PN
3 Gang Toggle Switch



Y08.2430.PN
4 Gang Toggle Switch



Y08.2401.PN
1 Gang Intermediate Toggle
Switch

Stockholm Toggle Switches



Y08.8400.PN
1 Gang Stockholm
Toggle



Y08.8410.PN
2 Gang Stockholm
Toggle



Y08.8420.PN
3 Gang Stockholm
Toggle




Y08.8430.PN
4 Gang Stockholm
Toggle




Y08.8401.PN
1 Gang Intermediate Stockholm
Toggle


Multi Location Dimmers (Compatible with LED bulbs)




Y08.260.MLP
1G Multi Location Primary
Dimmer




Y08.260.MLS
1G Multi Location Secondary
Dimmer




Y08.270.MLP
2G Multi Location Primary
Dimmer




Y08.270.MLS
2G Multi Location Secondary
Dimmer




Y08.280.MLP
3G Multi Location Primary Dimmer



Y08.280.MLS
3G Multi Location Secondary Dimmer




Y08.290.MLP
4G Multi Location Primary Dimmer




Y08.290.MLS
4G Multi Location Secondary Dimmer


TED Dimmer Switches (Compatible with LED bulbs)




Y08.260.TED
1 Gang TED Dimmer (Compatible with LED Lamps)



Y08.270.TED
2 Gang TED Dimmer (Compatible with LED Lamps)




Y08.280.TED
3 Gang TED Dimmer (Compatible with LED Lamps)




Y08.290.TED
4 Gang TED Dimmer (Compatible with LED Lamps)


Dimmer Switches (Compatible with halogen/ incandescent bulbs)




Y08.260.250
1 Gang Dimmer 250 watts (Compatible with halogen/ incandescent bulbs)




Y08.260.400
1 Gang Dimmer 400 watts (Compatible with halogen/ incandescent bulbs)



Y08.270.250
2 Gang Dimmer 250 watts (Compatible with halogen/ incandescent bulbs)




Y08.270.400
2 Gang Dimmer 400 watts (Compatible with halogen/ incandescent bulbs)




Y08.280.250

3 Gang Dimmer 250 watts (Compatible with halogen/ incandescent bulbs)




Y08.280.400

3 Gang Dimmer 400 watts (Compatible with halogen/ incandescent bulbs)



Y08.290.250


4 Gang Dimmer 250 watts (Compatible with halogen/ incandescent bulbs)




Y08.290.400

4 Gang Dimmer 400 watts (Compatible with halogen/ incandescent bulbs)


Mixed Toggle Dimmer Switches




Y08-1TOG-1TED
2G 1xToggle 1xTED




Y08-2TOG-1TED
3G 2xToggle 1xTED




Y08-1TOG-2TED
3G 1xToggle 2xTED



Y08-3TOG-1TED
4G 3xToggle 1xTED




Y08-2TOG-2TED
4G 2xToggle 2xTED




Y08-1TOG-3TED
4G 1xToggle 3xTED


Plug Sockets




Y08.240.PNW
Single Socket (13 Amp)



Y08.240.PNBK
Single Socket (13 Amp)




Y08.250.PNW
Double Socket (13 Amp)




Y08.250.PNBK
Double Socket (13 Amp)


USB Sockets




C-Y08.2559.PNW
2G 13A Socket with USB-A+C



C-Y08.2559.PNB
2G 13A Socket with USB-A+C




C-Y08.2459.PNB
1G 13A Socket with USB-A+C




C-Y08.2459.PNW
1G 13A Socket with USB-A+C

Unswitched Socket




Y08.282.W
5 Amp 3 Round Pin Socket




Y08.282.BK
5 Amp 3 Round Pin Socket


Cooker Switches



Y08.263.PN
45A DP Cooker Switch with Neon (single plate)




Y08.262.PNW
45A Cooker Unit + 13A Socket




Y08.262.PNBK
45A Cooker Unit + 13A Socket

Shaver Sockets




Y08.285.W
Shaver Socket Output Voltage
110/240V




Y08.285.BK
Shaver Socket Output Voltage
110/240V

Key Card Switch




Y08.7905.BK
Key Card Switch




Y08.7905.W
Key Card Switch


Fused Spur Units




Y08.234.W
Unswitched Spur (13
Amp)




Y08.234.BK
Unswitched Spur (13
Amp)




Y08.235.PNW
Switched Spur (13 Amp)




Y08.235.PNBK
Switched Spur (13 Amp)




Y08.236.PNW
Switched Spur with Neon (13
Amp)



Y08.236.PNBK
Switched Spur with Neon (13
Amp)




Y08.238.PNW
Switched Spur with Neon + Cord (13
Amp)




Y08.238.PNBK
Switched Spur with Neon + Cord (13
Amp)

Double Pole Switches




Y08.205.PN
20A Double Pole Switch




Y08.206.PN
20A Double Pole Switch with
Neon

Fan Isolator Switches




Y08.2990.PN
6A Triple Pole Fan Isolator
Switch


TV and Satellite Sockets




Y08.221.W
1 Gang Non-Isolated TV Coaxial
Socket




Y08.221.BK
1 Gang Non-Isolated TV Coaxial
Socket




Y08.223.W
1 Gang Isolated TV Coaxial
Socket




Y08.223.BK
1 Gang Isolated TV Coaxial
Socket




Y08.222.W
2 Gang TV Coaxial
Socket




Y08.222.BK
2 Gang TV Coaxial
Socket




Y08.224.W-DIP
TV/FM Diplexed Socket




Y08.224.BK-DIP
TV/FM Diplexed Socket




Y08.225.W
1 Gang Satellite Socket



Y08.225.BK
1 Gang Satellite Socket




Y08.226.W
TV/Satellite Socket




Y08.226.BK
TV/Satellite Socket


Telephone and Data Sockets




Y08.266.W-S
1 Gang Secondary Line
Socket




Y08.266.BK-S
1 Gang Secondary Line
Socket




Y08.267.W-M
1 Gang Master Line
Socket




Y08.267.BK-M
1 Gang Master Line
Socket




Y08.256.W-S
2 Gang Secondary Line
Socket




Y08.256.BK-S
2 Gang Secondary Line
Socket




Y08.257.W-M
2 Gang Master Line
Socket




Y08.257.BK-M
2 Gang Master Line
Socket




Y08.268.W-RJ45
1 Gang RJ45




Y08.268.BK-RJ45
1 Gang RJ45




Y08.269.W-RJ11
1 Gang RJ11




Y08.269.BK-RJ11
1 Gang RJ11




Y08.258.W-RJ45
2 Gang RJ45




Y08.258.BK-RJ45
2 Gang RJ45




Y08.268.W-CAT6
1 Gang CAT6



Y08.268.BK-CAT6
1 Gang CAT6




Y08.258.W-CAT6
2 Gang CAT6




Y08.258.BK-CAT6
2 Gang CAT6


Euro Module Plates



PL.Y08.2691.G
1 Module Euro Plate




PL.Y08.2692.G
2 Module Euro Plate



PL.Y08.2694.G
4 Module Euro Plate

Blank Plates



Y08.231
Single Blank Plate



Y08.232
Double Blank Plate