

## STUDIO RANGE - POLISHED BRONZE

---

### Rocker Light Switches



Y07.200.BZ  
1 Gang Rocker Switch (10  
Amp)



Y07.210.BZ  
2 Gang Rocker Switch (10  
Amp)



Y07.220.BZ  
3 Gang Rocker Switch (10  
Amp)



Y07.230.BZ  
4 Gang Rocker Switch (10 Amp)



Y07.201.BZ  
1 Gang Intermediate Rocker Switch (10  
Amp)

---

### Classic Toggle Switches



Y07.2400.BZ  
1 Gang Toggle Switch



Y07.2410.BZ  
2 Gang Toggle Switch



Y07.2420.BZ  
3 Gang Toggle Switch



Y07.2430.BZ  
4 Gang Toggle Switch



Y07.2401.BZ  
1 Gang Intermediate Toggle  
Switch

---

### Stockholm Toggle Switches



Y07.8400.BZ  
1 Gang Stockholm  
Toggle



Y07.8410.BZ  
2 Gang Stockholm  
Toggle



Y07.8420.BZ  
3 Gang Stockholm  
Toggle



Y07.8430.BZ  
4 Gang Stockholm  
Toggle



Y07.8401.BZ  
1 Gang Intermediate Stockholm  
Toggle

---

## Multi Location Dimmers (Compatible with LED bulbs)



Y07.260.MLP  
1G Multi Location Primary  
Dimmer



Y07.260.MLS  
1G Multi Location Secondary  
Dimmer



Y07.270.MLP  
2G Multi Location Primary  
Dimmer



Y07.270.MLS  
2G Multi Location Secondary  
Dimmer



Y07.280.MLP  
3G Multi Location Primary Dimmer



Y07.280.MLS  
3G Multi Location Secondary Dimmer



Y07.290.MLP  
4G Multi Location Primary Dimmer



Y07.290.MLS  
4G Multi Location Secondary Dimmer

---

**TED Dimmer Switches (Compatible with LED bulbs)**



Y07.260.TED  
1 Gang TED Dimmer (Compatible with LED Lamps)



Y07.270.TED  
2 Gang TED Dimmer (Compatible with LED Lamps)



Y07.280.TED  
3 Gang TED Dimmer (Compatible with LED Lamps)



Y07.290.TED  
4 Gang TED Dimmer (Compatible with LED Lamps)

---

### Dimmer Switches (Compatible with halogen/ incandescent bulbs)



Y07.260.250  
1 Gang Dimmer 250 watts (Compatible with halogen/ incandescent bulbs)



Y07.260.400  
1 Gang Dimmer 400 watts (Compatible with halogen/ incandescent bulbs)



Y07.270.250  
2 Gang Dimmer 250 watts (Compatible with halogen/ incandescent bulbs)



Y07.270.400  
2 Gang Dimmer 400 watts (Compatible with halogen/ incandescent bulbs)



Y07.280.250

3 Gang Dimmer 250 watts (Compatible with halogen/ incandescent bulbs)



Y07.280.400

3 Gang Dimmer 400 watts (Compatible with halogen/ incandescent bulbs)



Y07.290.250

4 Gang Dimmer 250 watts (Compatible with halogen/ incandescent bulbs)




Y07.290.400


4 Gang Dimmer 400 watts (Compatible with halogen/ incandescent bulbs)

---


## Mixed Toggle Dimmer Switches




Y07-1TOG-1TED  
2G 1xToggle 1xTED




Y07-2TOG-1TED  
3G 2xToggle 1xTED




Y07-1TOG-2TED  
3G 1xToggle 2xTED



Y07-3TOG-1TED  
4G 3xToggle 1xTED



Y07-2TOG-2TED  
4G 2xToggle 2xTED



Y07-1TOG-3TED  
4G 1xToggle 3xTED

---

## Plug Sockets



Y07.240.BZBK  
Single Socket (13 Amp)




Y07.250.BZBK  
Double Socket (13 Amp)

---

## USB Sockets



C-Y07.2559.BZBK  
2G 13A Socket with USB-A+C



C-Y07.2459.BZBK  
1G 13A Socket with USB-A+C

---

## Unswitched Socket



Y07.282.BK  
5 Amp 3 Round Pin  
Socket

---

## Cooker Switches



Y07.263.BZ  
45A DP Cooker Switch with Neon (single  
plate)



Y07.262.BZBK  
45A Cooker Unit + 13A Socket

---


## Shaver Sockets



Y07.285.BK  
Shaver Socket Output Voltage  
110/240V

---

## Key Card Switch



Y07.7905.BK  
Key Card Switch

---


## Fused Spur Units




Y07.234.BK  
Unswitched Spur (13  
Amp)



Y07.236.BZBK  
Switched Spur with Neon (13  
Amp)



Y07.235.BZBK  
Switched Spur (13 Amp)



Y07.238.BZBK  
Switched Spur with Neon + Cord (13  
Amp)

---

**Double Pole Switches**



Y07.205.BZ  
20A Double Pole Switch



Y07.206.BZ  
20A Double Pole Switch with  
Neon

---


**Fan Isolator Switches**




Y07.2990.BZ  
6A Triple Pole Fan Isolator  
Switch

---


**TV and Satellite Sockets**




Y07.221.BK  
1 Gang Non-Isolated TV Coaxial  
Socket




Y07.223.BK  
1 Gang Isolated TV Coaxial  
Socket




Y07.222.BK  
2 Gang TV Coaxial  
Socket



Y07.224.BK-DIP  
TV/FM Diplexed Socket



Y07.225.BK  
1 Gang Satellite Socket



Y07.226.BK  
TV/Satellite Socket


---

**Telephone and Data Sockets**







Y07.266.BK-S  
1 Gang Secondary Line  
Socket




Y07.267.BK-M  
1 Gang Master Line  
Socket




Y07.256.BK-S  
2 Gang Secondary Line  
Socket




Y07.257.BK-M  
2 Gang Master Line  
Socket




Y07.268.BK-RJ45  
1 Gang RJ45




Y07.269.BK-RJ11  
1 Gang RJ11



Y07.258.BK-RJ45  
2 Gang RJ45




Y07.268.BK-CAT6  
1 Gang CAT6




Y07.258.BK-CAT6  
2 Gang CAT6

---


## Euro Module Plates



PL.Y07.2691.G  
1 Module Euro Plate



PL.Y07.2692.G  
2 Module Euro Plate



PL.Y07.2694.G  
4 Module Euro Plate

---

## Blank Plates



Y07.231  
Single Blank Plate



Y07.232  
Double Blank Plate