

# Heritage Brass

## VINTAGE RANGE - ANTIQUE BRASS

---

### Rocker Light Switches




X91.100.BK  
1 Gang Rocker Switch (10  
Amp)



X91.110.BK  
2 Gang Rocker Switch (10  
Amp)



X91.120.BK  
3 Gang Rocker Switch (10  
Amp)



X91.130.BK  
4 Gang Rocker Switch (10 Amp)



X91.101.BK  
1 Gang Intermediate Rocker Switch (10  
Amp)

---

### Classic Toggle Switches



X91.2400.AB  
1 Gang Toggle Switch



X91.2410.AB  
2 Gang Toggle Switch



X91.2420.AB  
3 Gang Toggle Switch



X91.2430.AB  
4 Gang Toggle Switch



X91.2401.AB  
1 Gang Intermediate Toggle  
Switch

---

### Stockholm Toggle Switches



X91.8400.AB  
1 Gang Stockholm  
Toggle



X91.8410.AB  
2 Gang Stockholm  
Toggle



X91.8420.AB  
3 Gang Stockholm Toggle



X91.8430.AB  
4 Gang Stockholm Toggle



X91.8401.AB  
1 Gang Intermediate Stockholm  
Toggle

---

### Multi Location Dimmers (Compatible with LED bulbs)



X91.260.MLP  
1G Multi Location Primary  
Dimmer




X91.260.MLS  
1G Multi Location Secondary  
Dimmer




X91.270.MLP  
2G Multi Location Primary  
Dimmer



X91.270.MLS  
2G Multi Location Secondary  
Dimmer



X91.280.MLP  
3G Multi Location Primary Dimmer



X91.280.MLS  
3G Multi Location Secondary Dimmer



X91.290.MLP  
4G Multi Location Primary Dimmer



X91.290.MLS  
4G Multi Location Secondary Dimmer

---


### TED Dimmer Switches (Compatible with LED bulbs)



X91.260.TED  
1 Gang TED Dimmer (Compatible with LED Lamps)



X91.270.TED  
2 Gang TED Dimmer (Compatible with LED Lamps)



X91.280.TED  
3 Gang TED Dimmer (Compatible with LED Lamps)



X91.290.TED  
4 Gang TED Dimmer (Compatible with LED Lamps)

---

### Dimmer Switches (Compatible with halogen/ incandescent bulbs)



X91.260.250  
1 Gang Dimmer 250 watts (Compatible with halogen/ incandescent bulbs)




X91.260.400  
1 Gang Dimmer 400 watts (Compatible with halogen/ incandescent bulbs)



X91.270.250  
2 Gang Dimmer 250 watts (Compatible with halogen/ incandescent bulbs)




X91.270.400  
2 Gang Dimmer 400 watts (Compatible with halogen/ incandescent bulbs)



X91.280.250

3 Gang Dimmer 250 watts (Compatible with halogen/ incandescent bulbs)



X91.280.400

3 Gang Dimmer 400 watts (Compatible with halogen/ incandescent bulbs)



X91.290.250

4 Gang Dimmer 250 watts (Compatible with halogen/ incandescent bulbs)



X91.290.400

4 Gang Dimmer 400 watts(Compatible with halogen/ incandescent bulbs)

---

## Mixed Toggle Dimmer Switches



X91-1TOG-1TED  
2G 1xToggle 1xTED



X91-2TOG-1TED  
3G 2xToggle 1xTED



X91-1TOG-2TED  
3G 1xToggle 2xTED




X91-3TOG-1TED  
4G 3xToggle 1xTED




X91-2TOG-2TED  
4G 2xToggle 2xTED




X91-1TOG-3TED  
4G 1xToggle 3xTED




XGL-1TOG-1TED  
2G 1xToggle 1xTED




XGL-2TOG-1TED  
3G 2xToggle 1xTED




XGL-1TOG-2TED  
3G 1xToggle 2xTED



XGL-3TOG-1TED  
4G 3xToggle 1xTED



XGL-2TOG-2TED  
4G 2xToggle 2xTED



XGL-1TOG-3TED  
4G 1xToggle 3xTED

---

## Plug Sockets



X91.140.BK  
Single Socket (13 Amp)




X91.150.BK  
Double Socket (13 Amp)

---

## USB Sockets



C-X91.7509.BK  
2G 13A Socket with USB-A+C



C-X91.7409.BK  
1G 13A Socket with USB-A+C

---

## Unswitched Socket



X91.182.BK  
5 Amp 3 Round Pin  
Socket

---

## Cooker Switches



X91.163.BK  
45A DP Cooker Switch with Neon (single  
plate)



X91.161.BK  
45A DP Cooker Switch with Neon (tall  
plate)



X91.162.BK  
45A Cooker Unit + 13A Socket

---

## Shaver Sockets



X91.185.BK  
Shaver Socket Output Voltage  
110/240V

---

### Fused Spur Units



X91.134.BK  
Unswitched Spur (13  
Amp)



X91.135.BK  
Switched Spur (13 Amp)



X91.136.BK  
Switched Spur with Neon (13  
Amp)



X91.138.BK  
Switched Spur with Neon + Cord (13  
Amp)

---

### Double Pole Switches



X91.105.BK  
20A Double Pole Switch



X91.106.BK  
20A Double Pole Switch with  
Neon

---

### Fan Isolator Switches



X91.1990.BK  
6A Triple Pole Fan Isolator  
Switch

---

### TV and Satellite Sockets



X91.121.BK  
1 Gang Non-Isolated TV Coaxial  
Socket



X91.123.BK  
1 Gang Isolated TV Coaxial  
Socket




X91.122.BK  
2 Gang TV Coaxial  
Socket



X91.125.BK  
1 Gang Satellite Socket



X91.126.BK  
TV/Satellite Socket



X91.224.BK-DIP  
TV/FM Diplexed Socket

---

## Telephone and Data Sockets



X91.166.BK-S  
1 Gang Secondary Line  
Socket



X91.167.BK-M  
1 Gang Master Line  
Socket



X91.156.BK-S  
2 Gang Secondary Line  
Socket



X91.157.BK-M  
2 Gang Master Line  
Socket



X91.168.BK-RJ45  
1 Gang CAT6



X91.158.BK-RJ45  
2 Gang CAT6

---

## Euro Module Plates



PL.X91.2691.G  
1 Module Euro Plate



PL.X91.2692.G  
2 Module Euro Plate



PL.X91.2694.G  
4 Module Euro Plate

---

## Blank Plates



X91.131  
Single Blank Plate



X91.132  
Double Blank Plate