

STUDIO RANGE - POLISHED BRASS

Rocker Light Switches




Y01.200.PB
1 Gang Rocker Switch (10
Amp)



Y01.210.PB
2 Gang Rocker Switch (10
Amp)



Y01.220.PB
3 Gang Rocker Switch (10
Amp)



Y01.230.PB
4 Gang Rocker Switch (10 Amp)



Y01.201.PB
1 Gang Intermediate Rocker Switch (10
Amp)

Classic Toggle Switches



Y01.2400.PB
1 Gang Toggle Switch



Y01.2410.PB
2 Gang Toggle Switch



Y01.2420.PB
3 Gang Toggle Switch



Y01.2430.PB
4 Gang Toggle Switch



Y01.2401.PB
1 Gang Intermediate Toggle
Switch

Stockholm Toggle Switches



Y01.8400.PB
1 Gang Stockholm
Toggle



Y01.8410.PB
2 Gang Stockholm
Toggle



Y01.8420.PB
3 Gang Stockholm Toggle



Y01.8430.PB
4 Gang Stockholm Toggle



Y01.8401.PB
1 Gang Intermediate Stockholm
Toggle

Multi Location Dimmers (Compatible with LED bulbs)



Y01.260.MLP
1G Multi Location Primary
Dimmer



Y01.260.MLS
1G Multi Location Secondary
Dimmer



Y01.270.MLP
2G Multi Location Primary
Dimmer



Y01.270.MLS
2G Multi Location Secondary
Dimmer



Y01.280.MLP
3G Multi Location Primary Dimmer



Y01.280.MLS
3G Multi Location Secondary Dimmer



Y01.290.MLP
4G Multi Location Primary Dimmer



Y01.290.MLS
4G Multi Location Secondary Dimmer

TED Dimmer Switches (Compatible with LED bulbs)



Y01.260.TED
1 Gang TED Dimmer (Compatible with LED Lamps)



Y01.270.TED
2 Gang TED Dimmer (Compatible with LED Lamps)



Y01.280.TED
3 Gang TED Dimmer (Compatible with LED Lamps)



Y01.290.TED
4 Gang TED Dimmer (Compatible with LED Lamps)

Dimmer Switches (Compatible with halogen/ incandescent bulbs)



Y01.260.250
1 Gang Dimmer 250 watts (Compatible with halogen/ incandescent bulbs)



Y01.260.400
1 Gang Dimmer 400 watts (Compatible with halogen/ incandescent bulbs)



Y01.270.250
2 Gang Dimmer 250 watts (Compatible with halogen/ incandescent bulbs)



Y01.270.400
2 Gang Dimmer 400 watts (Compatible with halogen/ incandescent bulbs)



Y01.280.250

3 Gang Dimmer 250 watts (Compatible with halogen/ incandescent bulbs)



Y01.280.400

3 Gang Dimmer 400 watts (Compatible with halogen/ incandescent bulbs)



Y01.290.250

4 Gang Dimmer 250 watts (Compatible with halogen/ incandescent bulbs)



Y01.290.400

4 Gang Dimmer 400 watts (Compatible with halogen/ incandescent bulbs)

Mixed Toggle Dimmer Switches



Y01-1TOG-1TED
2G 1xToggle 1xTED



Y01-2TOG-1TED
3G 2xToggle 1xTED



Y01-1TOG-2TED
3G 1xToggle 2xTED



Y01-3TOG-1TED
4G 3xToggle 1xTED



Y01-2TOG-2TED
4G 2xToggle 2xTED



Y01-1TOG-3TED
4G 1xToggle 3xTED


Plug Sockets




Y01.240.PBBK
Single Socket (13 Amp)



Y01.250.PBBK
Double Socket (13 Amp)



Y01.240.PBW
Single Socket (13 Amp)



Y01.250.PBW
Double Socket (13 Amp)


USB Sockets




C-Y01.2559.PBW
2G 13A Socket with USB-A+C



C-Y01.2559.PBK
2G 13A Socket with USB-A+C



C-Y01.2459.PBK
1G 13A Socket with USB-A+C




C-Y01.2459.PBW
1G 13A Socket with USB-A+C

Unswitched Socket



Y01.282.BK
5 Amp 3 Round Pin
Socket



Y01.282.W
5 Amp 3 Round Pin
Socket


Cooker Switches



Y01.263.PB
45A DP Cooker Switch with Neon (single
plate)



Y01.262.PBBK
45A Cooker Unit + 13A Socket




Y01.262.PBW
45A Cooker Unit + 13A Socket

Shaver Sockets




Y01.285.BK
Shaver Socket Output Voltage
110/240V




Y01.285.W
Shaver Socket Output Voltage
110/240V

Key Card Switch



Y01.7905.BK
Key Card Switch



Y01.7905.W
Key Card Switch

Fused Spur Units




Y01.234.BK
Unswitched Spur (13
Amp)




Y01.235.PBBK
Switched Spur (13 Amp)




Y01.236.PBBK
Switched Spur with Neon (13
Amp)




Y01.234.W
Unswitched Spur (13
Amp)




Y01.235.PBW
Switched Spur (13 Amp)



Y01.236.PBW
Switched Spur with Neon (13
Amp)



Y01.238.PBW
Switched Spur with Neon + Cord (13
Amp)




Y01.238.PBBK
Switched Spur with Neon + Cord (13
Amp)

Double Pole Switches




Y01.205.PB
20A Double Pole Switch



Y01.206.PB
20A Double Pole Switch with
Neon

Fan Isolator Switches



Y01.2990.PB
6A Triple Pole Fan Isolator
Switch

TV and Satellite Sockets



Y01.221.BK
1 Gang Non-Isolated TV Coaxial
Socket



Y01.223.BK
1 Gang Isolated TV Coaxial
Socket




Y01.222.BK
2 Gang TV Coaxial
Socket




Y01.225.BK
1 Gang Satellite Socket




Y01.226.BK
TV/Satellite Socket




Y01.221.W
1 Gang Non-Isolated TV Coaxial
Socket




Y01.223.W
1 Gang Isolated TV Coaxial
Socket




Y01.222.W
2 Gang TV Coaxial
Socket




Y01.224.W-DIP
TV/FM Diplexed Socket



Y01.224.BK-DIP
TV/FM Diplexed Socket



Y01.225.W
1 Gang Satellite Socket



Y01.226.W
TV/Satellite Socket

Telephone and Data Sockets



Y01.266.BK-S
1 Gang Secondary Line
Socket



Y01.267.BK-M
1 Gang Master Line
Socket



Y01.256.BK-S
2 Gang Secondary Line
Socket



Y01.257.BK-M
2 Gang Master Line
Socket



Y01.268.BK-RJ45
1 Gang RJ45



Y01.269.BK-RJ11
1 Gang RJ11




Y01.258.BK-RJ45
2 Gang RJ45




Y01.268.BK-CAT6
1 Gang CAT6




Y01.258.BK-CAT6
2 Gang CAT6




Y01.266.W-S
1 Gang Secondary Line
Socket




Y01.267.W-M
1 Gang Master Line
Socket




Y01.256.W-S
2 Gang Secondary Line
Socket




Y01.257.W-M
2 Gang Master Line
Socket




Y01.268.W-RJ45
1 Gang RJ45




Y01.269.W-RJ11
1 Gang RJ11



Y01.258.W-RJ45
2 Gang RJ45




Y01.268.W-CAT6
1 Gang CAT6




Y01.258.W-CAT6
2 Gang CAT6


Euro Module Plates



PL.Y01.2691.G
1 Module Euro Plate



PL.Y01.2692.G
2 Module Euro Plate



PL.Y01.2694.G
4 Module Euro Plate

Blank Plates



Y01.231
Single Blank Plate



Y01.232
Double Blank Plate

Dimmer Knobs



KNU600.01
Dimmer Knobs



K565.01
Dimmer Knobs